


18. COMPONENTES / COMPONENTS

Componentes/Components



COMPONENTES	SPARE PARTS
50 Paragoteo	50 Drip washer
55 Turbina	55 Impeller
58 Difusor	58 Diffuser
60 Junta difusor	60 Diffuser gasket
61 Junta cuerpo bomba	61 Pump housing gasket
62 Cuerpo bomba	62 Pump housing
64 Cesta filtro	64 Prefilter basket
65 Junta tapa filtro	65 Prefilter cover gasket
66 Tapa filtro	66 Prefilter cover
67 Palomilla	67 Knob
77 Tuerca sujeción palomilla	77 Fixing thumb nut
78 Cuerpo intermedio	78 Intermediate housing
80 Sello mecánico	80 Mechanical seal
202 Tapón y junta desagüe	202 Drain plug and drain plug gasket